

Пароманекены и парокабинеты 340

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: mip@nt-rt.ru || сайт: <https://macpi.nt-rt.ru/>



MACPI 340

340 is an innovative fusing machine with kinematics motions and heating system designed to reduce the running cost. This machine comes available with two different belt widths of 1000 mm and 1400 mm. The modular heating system, core of the machine, allows the use of steam for the belt heating granting unreachable performances. The pressing is made of two silicone coated rollers with electronic pressure control able to work with a wide range of fabrics.



362.01

MACHINE FOR FABRIC FOLDING

Electropneumatic machine for straight folding of garments with the possibility of inserting mono- or bi-adhesive supports.

The machine is featuring the following characteristics and is complete with:

- * automatic exit of creasing blades during the pressing process
- * heated and steaming upper plate
- * heated lower plate with vacuum in two different sections, with separate controls
- * working width of 1700mm
- * adjustable reference for the fold depth
- * automatic fabric holding clamps in 5 different positions with single controls and automatic release
- * Touch Screen

341.46-2404 CONTINUOUS MELTING MACHINE



CONTINUOUS MELTING MACHINE, divided into the following sections:

Inverter-controlled cold loading conveyor - length 1250 mm

Heating (see note), pre-melting, melting with separate cylinder drive

Inverter-controlled unloading conveyor - length 1250 mm

The machine has the following features and is equipped with:

Two working widths available: 1400 mm - 1600 mm

TCW color terminal for 7" programming with USB and Wi-Fi.

Automatic shut-off

Melting pressure from 0 to 6 Atm with 1/2 pair of cylinders

Band speed from 2 to 10 m/min, programmable and inverter controlled

No. 3 programmable thermostats (preheating plate 1°, plate 2°)

Automatic signaling of "machine ready" or abnormal operation

Belt cleaning device, two internal and two external.

Detachment of the molten tissue using a carbon blade

HEATING

The machine's heating system is available in 3 versions:

341. **. * 1 **: Steam heating only. The maximum temperature that can be reached on the fabric is 10°C lower than the steam cooking temperature.

341. **. * 2 **: electric heating only

341. **. * 4 **: heating by both steam and electricity, favoring steam when present and until its temperature reaches

The machine is already adapted to be connected to the Mod.985 automatic loader and the Mod.978 unloader.

CONNECTIONS

Compressed air connection at 6 Atm.

For machines with type 1 and 4 heating, a steam connection is required.

Power supply: 3 ~ 50Hz 230V - 3 + N ~ 50Hz 400V

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: mip@nt-rt.ru || сайт: <https://macpi.nt-rt.ru/>