

Пароманекены и парокабинеты

389

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: mip@nt-rt.ru || сайт: <https://macpi.nt-rt.ru/>

389.20 DUMMY FOR APPAREL

Electropneumatic dummy for the simultaneous ironing of shirts body, shoulders and sleeves.

The dummy is featuring the following characteristics and is complete with:

- * blowing and vacuum unisex dummy with collar locking
- * electrically heated front paddle for shirt front placket locking and ironing
- * pneumatic devices for side adjustment, front and rear blocking of bottom shirts and shirt tension
- * turning and retractable front paddle to facilitate the loading and unloading operations
- * clamps with photocell closure and sleeve tensioning with mechanical limit switch
- * built-in electric fan of 2,25Kw
- * cold air blowing
- * heated air blowing adjustment by inverter
- * built-in vacuum fan of 0,56 kw
- * adjustable ironing pressure for front paddle, for sides
- adjustment devices for shirt traction
- * Touch Screen programmer TC7"
- * adaption for use of dummy of different sizes:
 - * man 8577
 - * woman 8575
 - * child 8574
- * steam heating system
- * steam consumption 30/40 Kg/h



389.21 MANNEQUIN FOR SHIRT FINISHING

Shirt mannequin with steam heating (wet/spin-dry shirts)

Electropneumatic mannequin for simultaneous pressing of the body, shoulders and short/long sleeves of shirts, complete with:

- Unisex blowing and suction mannequin with collar lock and pneumatic shoulder width adjustment;
- Electric heated front plate for locking and pressing the shirt's front button placket
- Pneumatic devices for lateral adjustment, front and rear locking of the shirt tail and full traction
- Swiveling and translucent front plate to facilitate loading/unloading operations;
- Adjustable tension darts with automatic closure of the cuffs and sleeves
- Integrated 2.25 kW electric fan for air blowing;
- Integrated vacuum fan 0.56 kw;
- Steam overheating;
- Adjustable pressure for the front plate, for the side adjustment devices, for shirt traction and cuffs and short sleeve expansion;
- 5.7" Touchscreen Programmer



389.

DUMMY FOR SHIRTS

Electropneumatic dummy for simultaneous pressing of body, shoulders and short/long sleeves of shirts, complete with:



- Blowing and vacuum unisex dummy with collar locking and pneumatic adjustment of the shoulder width;
- Electrical heated front plate for shirt front placket locking and pressing;
- Pneumatic devices for side adjustment, front and rear locking of shirt tail and complete traction;
- Adjustable and tensioning clamps with automatic closure of cuffs and sleeve;
- Blowing hot air adjustable by inverter;
- Adjustable pressing pressure for front plate, for side adjustment devices, for shirt traction and cuffs and short sleeves expansion;
- Programmer touch screen 5,7" - Usb port
- Version 21 - with steam heating, steam overheat-er.
- Version 23 - with electric heating, electric thermal exchange battery 24 Kw.

Technical details

- 389.21** **Dimension:** (mm W x H x D) 2700 x 1600 x 830 | **Weight:** 270 Kg
Built-in electric fan 2,25 Kw for air blowing | **Built-in vacuum** fan 0,56 kw
Adaption for connection to the main steam, and **compressed air** plants (6 Bar)
Steam consumption 30/40 Kg/h | **Installed power:** Kw 3,8 | **Voltage:** 3~50Hz 230 V - 3+N~50Hz 400 V
- 389.23** **Dimension:** (mm W x H x D) 2700 x 1600 x 830 | **Weight:** 270 Kg
Built-in electric fan 2,25 Kw for air blowing | **Built-in vacuum** fan 0,56 kw
Adaption for connection to the main steam, and **compressed air** plants (6 Bar)
Installed power: Kw 27,8 | **Voltage:** 3~50Hz 230 V - 3+N~50Hz 400 V

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: mip@nt-rt.ru || сайт: <https://macpi.nt-rt.ru/>